

# How do you store your tent?

## Directions for storage

### Roll it up dry

Never roll up the tent while it is still wet. If you have no alternative, roll it out again to dry as quickly as possible – at any rate, within 24 hours.

### Use a breathable storage bag

Ensure that the bag in which you store the tent provides good ventilation. Preferably a cotton – thus breathable – storage bag should be used. Never wash the bag with soap.

### Store any extras separately

Always store the ground sheet, the rings, guy ropes, curtains and mud skirts separately – not in the same storage bag as the tent. The ground sheet and mud skirts may contain substances that will affect the tent cloth; lines and rings may cause damage.

### Ventilation in the storage area

Store the tent clean and dry in a well ventilated area.

If you follow this advice, you will be able to fully enjoy your tent, the TenCate tent cloth and your camping holiday again next time.

For further advice, please contact your camping specialist store.

For more information about TenCate and TenCate tent cloth check [www.tencateoutdoorfabrics.com](http://www.tencateoutdoorfabrics.com)

