

Tips for storing your tent

- Ensure that the tent is clean and dry (do not clean with soap!) before storing it in a dry and well-ventilated area.
- The bag in which you store the tent should preferably be of a well-ventilated material, such as cotton.
- The cotton storage bag must definitely not be washed with soap, as cleaning agents can damage the waterproof qualities of the canvas.
- Do not pack rings, guy ropes, curtains, ground sheet and mud skirts in the same bag as the tent. The ground sheet and mud skirts may contain substances damaging to the canvas, and the ropes and rings may also damage the canvas.

