



CONSTRUCTION SEQUENCE

- EXCAVATE FOR LEVEL BASE TO A LENGTH ADEQUATE FOR REINFORCEMENT EMBEDMENT.
- SET GRADING STAKES AT A 6" OFFSET TO FACILITATE PROPER BASKET ALIGNMENT.
- EMBED BOTTOM BASKET 6" BELOW FINISHED GRADE AT FRONT FACE OF WALL OR AS SHOWN ON WALL PROFILE.




STEP 1

- FOR THE FIRST COURSE OF THE WALL, ALIGN BASKETS WITHOUT SPACES AND HOG RING TOGETHER
- INSTALL STRUTS AT ABOUT 24" SPACING




STEP 2

- PLACE PRIMARY REINFORCEMENT (MIRAGRID GEOGRID) AT ELEVATIONS SHOWN ON WALL PROFILE DRAWING.
- DRAPE MMESH FABRIC OVER BASKET ALLOWING FOR THE REQUIRED WRAP EMBEDMENT




STEP 3

- BACKFILL CAREFULLY TO ABOUT 1" - 2" ABOVE THE TOP HORIZONTAL BASKET WIRE OR AS REQUIRED BY THE ENGINEER
- COMPACT TO REQUIRED DENSITY.




STEP 4

- PULL MMESH BACK OVER COMPACTED FILL AND ANCHOR WITH SOIL.
- SLIDE THE NEXT BASKET BACK AGAINST THE PRONGS OF THE LOWER MAT AND HOG RING USING RUNNING BOND (STAGGERED).
- INSTALL HOG RINGS AND STRUTS TO SECOND LIFT.




STEP 5

- REPEAT STEPS 2 THRU 5 UNTIL DESIRED HEIGHT OF WALL IS REACHED.



STEP 6

- BASKETS OFFSET FOR INCREASED VEGETATION GROWTH.



STEP 6 (OPTIONAL)

CONSTRUCTION DETAIL

VEGETATED MIRAMESH FACE
WALL W/ WIRE BASKET

TENCATE

365 SOUTH HOLLAND DRIVE
PENDERGRASS, GA 30567

